

# BLS 4000 ne»xt

## FILTERS ASSEMBLY INSTRUCTIONS, WEARING AND "DROP-OFF" PROCEDURE

### FILTER ASSEMBLY



Place the filter on the filter holder, aligning the point (1) with the arrow (2), as shown on the left.



Turn the filter clockwise until it stops and repeat the procedure for both filters

### WEARING PROCEDURE



1

Stretch the elastics and hold the lower hooks hooking them behind the neck.



2

Place the half mask on the nose and mouth and at the same time place the harness on the head.



3

Act on the adjustment of all the elastics to obtain a good adaptation of the mask to the face.



4

Inhale, pressing the palms of the hands against the filter ; if the oronasal collapses towards the face it means that the half-mask is well positioned and tight. Otherwise, improve the positioning of the mask on the face and eventually increase the tension of the elastic bands.

### DROP-OFF PROCEDURE



1

Once the half-mask is worn, release the lower elastic bands from behind the neck.



2

Keeping the harness on the head, grasp the mask and move it away from the face.



3

Pull the oronasal downwards, sliding the elastics into the front mask, to the point of maximum length.



4

To reposition the half-mask on the face, hold the lower hooks and pull the oronasal upwards; place the mask on the nose and mouth and hang up the lower hooks behind the neck. Proceed with the adjustment of the elastics and the fit testing.